

Fig. 1




Fig. 2

Description	Type	Size 80 (3 in.)	Size 100 (4 in.)	Size 125 (5 in.)	Size 150 (6 in.)
		Code no.	Code no.	Code no.	Code no.
Spare part kit, for top/housing and cap (Dismounting set)	all	148G3427	148G3428	148G3429	148G3430
Pos. 17 Gasket top/housing 36 O-ring for cap					
Repair kit, complete set of gaskets	all	148G3431	148G3432	148G3433	148G3434
Pos. 17 Gasket top/housing 18 Teflon ring cone step 2 19 Teflon ring cone step 1 25 O-ring piston inside 26 O-ring piston outside 27 Glide ring piston outside 28 O-ring guide 29 Glide ring guide 30 Glide ring piston inside 34 O-ring for connection part / solenoid valve 35 O-ring for threaded rod 36 O-ring for cap 39 Gasket for cylinder top 40 Gasket for cylinder					
Complete pilot valve block type EVRB without coils	all	2453+103	2453+103	2453+103	2453+103
Pos. 31 EVRB valve block 32 Bolts for solenoid valve 34 O-ring for connection part / solenoid valve					
Coil set, 24 V, 50 Hz	all	2425+377	2425+377	2425+377	2425+377
Coil set, 110 V, 60 Hz	all	2425+378	2425+378	2425+378	2425+378
Coil set, 220/230 V, 50 Hz	all	2425+379	2425+379	2425+379	2425+379
Coil set, 220 V, 60 Hz	all	2425+380	2425+380	2425+380	2425+380
External/pilot connection complete, fig. 2	all	2469+009	2469+009	2469+009	2469+009