



Danfoss
A148B245.10.10

Fig. 1, SVA-DH

	Size DN 250 (10 in.)	Size DN 300 (12 in.)
Description	Code no.	Code no.
Spare part kit, for bonnet and cap	148B4162	148B4163
Pos. 13 Gasket for bonnet		
18 Gasket		
19 Gasket for backseat		
Spare part kit for cone	148B4164	148B4165
Pos. 25 Gasket for cone (u-sleeve)		
26 Wear ring for cone		
27 Gasket for cone (valve seat)		
Packing gland (complete)	148B4166	148B4166
Pos. 8 Packing gland complete		
Complete repair kit	148B4167	148B4168
Pos. 8 Packing gland complete		
13 Gasket for bonnet		
18 Gasket		
19 Gasket for backseat		
25 Gasket for cone (u-sleeve)		
26 Wear ring for cone		
27 Gasket for cone (valve seat)		
Handwheel incl. nut and washer	148B4169	148B4170
Pos. 14 Handwheel		
15 Washer		
16 Nut		
Cap incl. Gasket	148B4171	148B4171
Pos. 17 Cap		
18 Gasket		
Grease for packing gland (tube)	2452+143	2452+143