



		NRVA 15/20	NRVA 25/32	NRVA 40/50	NRVA 65
Description	Qty	Code no.	Code no.	Code no.	Code no.
Piston assembly		020-2104	020-2105	020-2106	020-2107
Pos. 3 Piston assembly	1				
Valve seat		020-2127	020-2128	020-2129	020-2130
Pos. 12 Valve seat	1				
Spring (0.12 bar)		020-2137	020-2138	020-2139	020-2140
Pos. 5 Spring	1				
Spring (0.30 bar)		020-2307	020-2317	020-2327	020-2337
Pos. 5 Spring	1				
Complete valve without flanges		020-2020	020-2022	020-2024	020-2026
Pos. 1 Valve assembly	1				
11 Flange gasket	2				
Flange gaskets		020-2133	027F2176	027F2178	020-2136
Pos. 11 Gaskets	2				