



Fig. 1, DSV 1

Description	Code no.	Size 25 (1 in.)
<b>Spare part kit, for bonnet and cap</b> (installation kit)	<b>148F3022</b>	
Pos. 16 O-ring for seat		
17 O-ring for housing/bonnet		
23 Gasket for cap		
<b>Dismounting kit</b>	<b>148F3029</b>	
Pos. 30 Gasket for reducer SFV 15/DSV 1		
31 Gasket for reducer SFV 15/DSV 1		
32 Gasket for nipple SFV 15/DSV 1		
<b>Repair kit, complete set of gaskets</b>	<b>148F3024</b>	
Pos. 8 Gasket for cone		
16 O-ring for seat		
17 O-ring for housing/bonnet		
18 Lock pin		
20 Slotted nut		
23 Gasket for cap		
29a Gaskets complete for packing gland		
30 Gasket for reducer SFV 15/DSV 1		
31 Gasket for reducer SFV 15/DSV 1		
32 Gasket for nipple SFV 15/DSV 1		
<b>Packing gland incl. gaskets</b> (with O-rings)	<b>148B4032</b>	
Pos. 29 Packing gland incl. gaskets		
<b>Cap incl. gasket</b>	<b>148B4076</b>	
Pos. 28 Cap incl. gasket		
<b>Grease for packing gland</b> (tube)	<b>2452+143</b>	